

## Description

MX addressable manual stations contain an integral addressable module that constantly monitors status, and communicates changes to the connected FACU through MX communication wiring.

## Features

### Main features:

- MX addressable loop communications using a single wire pair
- EMI compatibility
- Choice of hard addressing with DIP switch, or soft addressing with digital enrollment
- Internally mounted addressable module similar to the design of the 4090-5258 Mini-IAM
- Available with single-action breakglass, double-action breakglass, or double-action push-type operation
- Pull lever that protrudes when the device is alarmed
- Break-rod supplied for optional use
- UL listed to Standard 38

### Compatibility:

For use with Simplex® models 2050, 2250, 4007ES, 4010ES, and 4100ES series fire alarm control units (FACUs) with MX communications

### Compact construction:

- Electronics module enclosure minimizes dust infiltration
- Mounts in standard electrical boxes
- Screw terminals for wiring connections

### Security:

- Tamper-resistant reset key
- The lock shares the same key as the Simplex fire alarm cabinet.
- To reduce waste, pull stations do not include a key.

**Note:** Order keys separately. For ordering information, see [Table 2](#).

### Multiple mounting options:

- Surface or semi-flush with standard boxes or matching Simplex boxes
- Flush mount adapter kit
- Adapters are available for retrofitting to commonly available existing boxes

## Operation

**Activation** of the 4099-5214 single-action manual station requires a firm downward pull to activate the alarm switch. Pulling the switch breaks an internal plastic break-rod that is visible below the pull lever, use is optional. The break-rod is visible below the pull level to deter vandalism. You do not require additional force to pull the level with the break-rod in place. The pull lever latches into the alarm position and remains extended out of the housing to provide a visible indication.

**Double-action breakglass stations:** Strike the glass with the front-mounted hammer to expose the recessed pull lever. The pull lever then operates as a single action station.

**Double-action push-type stations:** To access the pull lever on double-action push-type stations, push the spring-loaded plate marked **PUSH**. The pull lever then operates as a single-action station.

**Station reset:** Use a key to reset the manual station lever and deactivate the alarm switch. If you use the break-rod, you must replace it.

**Station testing:** Pull the lever to test the station. Electrical testing works by unlocking the station housing to activate the alarm switch.

**Institutional stations** activate by key operation only. Manual alarm access can be limited to authorized personnel. Operation requires key insertion and opening of the station cover.

Figure 1: 4099-5214 Single action manual station, front and side view




Figure 2: 4099-5214 Single action manual station with institutional cover, ordered separately



Figure 3: 4099-5215 Double action breakglass manual station




Figure 4: 4099-5216 Double action push-type manual station



\* Additional listings may be applicable; contact your local Simplex product supplier for the latest status. Listings and approvals under Simplex Time Recorder Co. are the property of Tyco Fire Protection Products.

## MX Technology addressable manual station product selection

**Table 1: Addressable manual stations, red housing with white letters and white pull lever**

Model	Description
4099-5214	Single-action operation
4099-5215	Double-action, breakglass operation
4099-5216	Double-action, push-type operation

**Table 2: Accessories**


Model	Description
2975-9178	Surface mount steel box, red, see <a href="#">Figure 6</a> for details
2975-9022	Cast aluminum surface mount box, red, see <a href="#">Figure 6</a> for details
2099-9813	Semi-flush trim plate for double gang switch box, red, see <a href="#">Figure 8</a> for details
2099-9814	Surface trim plate for wiremold box V5744-2, red, see <a href="#">Figure 8</a> for details
2099-9819	Flush mount adapter kit, black, see <a href="#">Figure 9</a> for details
2099-9820	Flush mount adapter kit, beige, see <a href="#">Figure 9</a> for details
2099-9803	Replacement breakglass
2099-9804	Replacement break-rod
2099-9828	Institutional cover kit for field installation on 4099-5214
252-019	B key for pull station activation and reset

## Specifications

**Table 3: Specifications**

Specifications	Rating
Power and communications	MX Loop, one address for each manual station
Address means	Hard addressing using a DIP switch or soft addressing using Digital Enrollment with a QR code
Standby/Alarm current	Standby 0.043 mA / Alarm 4.51 mA
Wire connections	Terminal blocks, for wire size 20 AWG to 14 AWG (0.5 mm <sup>2</sup> to 2.5 mm <sup>2</sup> )
UL listed temperature range	32°F to 120°F (0°C to 49°C), this is intended for indoor operation
Humidity range	Up to 93% RH at 90°F (32°C)
Housing color	Red with white raised lettering
Material	Housing and pull lever are Lexan polycarbonate or equal
Pull Lever color	White with red raised lettering
Housing dimensions	5 in. H x 3 3/4 in. W x 1 in. D (127 mm x 95 mm x 25 mm)
Installation instructions	579-1429

## Addressable manual station semi-flush mounting

**Figure 5: Addressable manual station semi-flush mounting**



The European Single Gang Box has a minimum depth of 35 mm (1 3/8 in.). Use the box with only two mounting tabs. Supplied separately.

**Addressable manual stations surface mounting**

Preferred mounting: To surface mount addressable manual stations, the preferred electrical boxes are shown in [Figure 6](#).

Additional mounting reference: For Wiremold box mounting compatibility, see [Addressable manual station, additional mounting information](#)


**Figure 6: 4099 mounting**



Callout	Description
A	Box 5 3/16 in. x 4 in. x 2 3/16 in., 132 mm x 102 mm x 56mm (Height x Width x Depth) Ordered separately
B	Cast box 5 in. x 3 7/8 in. x 2 3/16 in., 127 mm x 98 mm x 56 mm (Height x Width x Depth) Ordered separately
C	Access for 3/4 in. threaded conduit located top and bottom
D	Series Addressable Manual Station
E	Knockouts located top and bottom

Surface mount side view with internal detail

Figure 7: Internal detail



Callout	Description
A	Rear view
B	Box
C	Field wiring. Shown for reference
D	Switch wiring. Pre-wired
E	Station cover hinges open for installation access

**Application reference**


Refer to NFPA 72, the *National Fire Alarm and Signaling Code*, and all applicable local codes for complete requirements for manual stations. The following summarizes the basic requirements.

- Locate stations in the normal path of exit and distribute in the protected area so that they are unobstructed and readily accessible.
- Mount with the operable part not less than 3 1/2 ft (1.1 m) and not more than 4 1/2 ft (1.37 m) above floor level.
- Provide at least one station on each floor. Provide additional stations to obtain a travel distance not more than 200 ft (61 m) to the nearest station from any point in the building.
- When manual station coverage appears limited in any way, install additional stations.

**Addressable manual station, additional mounting information**

For retrofit and new installations, additional compatible mounting boxes and the required adapter plates are shown in [Figure 8](#).


**Figure 8: Additional mounting information**



Callout	Description
A	Surface trim for Wiremold box 5 1/8 in. x 5 in., 130mm x 127 mm (Height x Width)
B	Wiremold receptacle box model V5744-1 Supplied by others
C	Two gang switch box, each 3 in. x 2 in. x 2 3/4 in., 76 mm x 51 mm x 70 mm (Height x Width x Depth) Supplied by others
D	Semi-flush trim for 2 gang switch box 6 in. x 4 1/2 in., 152 mm x 114 mm (Height x Width)

**Addressable manual station, flush mounting information**

Figure 9: Flush mounting information



Callout	Description
A	Flush mount adapter kit in black or beige
B	Box must be recessed into the wall by 1 in. to 1 1/8 in. (25.4 mm to 29 mm)
C	4 11/16 in. (119 mm) square box 2 1/8 in. (54 mm) minimum depth By others
D	Side view
E	Wall surface
F	Hole cutout must be a min. of 6 in. by 5 in., 152 mm x 127 mm (Height x Width)
G	Front view